



**INSTALLATION INSTRUCTIONS**  
**Ford RPM Air-Gap 302 Manifold**  
**For Small Block Ford Engines**  
**Catalog #7521**

---

•**Please** study these instructions carefully before installing your new intake manifold. If you have any questions or problems, please call our **Technical Hotline at: 1800-416-8628**, 7:00 am – 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at [edelbrock@edelbrock.com](mailto:edelbrock@edelbrock.com).

## **IMPORTANT NOTICE!**

---

**This supersedes Installation Instruction Step 1 included with the manifold.**

**USE MR. GASKET #203 INTAKE GASKETS WHEN INSTALLING THIS MANIFOLD!**

**For a proper seal around the bottom of the rear water outlets, embossed (stock OEM) or Printoseal style gaskets are not recommended.**

When installing your manifold with the #203 gasket we recommend applying a small amount of silicon around both the front and rear water passages.

**These special precautions must be taken to prevent coolant from leaking into the valley of your engine!**

THANK YOU.