



CDI P/N: 193-2905

# Installation and Troubleshooting Guide

All rights reserved. Reproduction or use of content, in any manner, without express written permission by CDI Electronics, Inc., is prohibited.

This unit replaces P/N: 582905

## WARNINGS:

**This product is designed for installation by a professional marine mechanic. CDI cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.**

**DO NOT USE A MAINTAINENCE FREE, AGM OR DRY CELL BATTERY WITH THIS TYPE REGULATOR/RECTIFIER AS THIS WILL VOID THE WARRANTY !!!**

**NEVER DISCONNECT THE BATTERY WHILE THE ENGINE IS RUNNING AS THIS MAY BURN OUT THE REGULATOR/RECTIFIER. *If the boat is equipped with a battery switch, make sure that it is a make before break type.***

1. Disconnect the negative battery post.
2. Disconnect and remove the old regulator/rectifier.
3. Use heat-sink compound (available at Radio Shack and other electronic supply stores) on the back of the regulator when you install the new regulator/rectifier.
4. Connect the new rectifier/regulator to the stator (ignore any stripes on the stator as the new rectifier/regulator does not require the Yellow wires to be connected to a particular stator wire).
5. Install the replacement regulator/rectifier using the bolts supplied.

*INSTALLATION NOTE: These regulator/rectifiers will cause a small spark when you reconnect the battery and will draw a very small amount of current from the battery (Less than 0.001 amp).*

## Troubleshooting

### Tachometer

1. At 800-1000 RPM, check output on the gray wire, reading should be at least 8 volts with a DVA meter. A low reading usually indicates a bad regulator if the system is charging the battery.
2. Check the resistance between the gray wire and engine ground. You should read above 100K (100,000) ohms. Gray to red, and gray to the yellow wires should be a high reading, usually in the M range.

### Maximum Output Test

1. Install an ammeter capable of reading at least 40 amperes in-line on the red wire connected to the starter solenoid.
2. Connect a load bank to the battery.
3. In the water or on a Dynamometer, start the engine and bring the RPM up to approximately 4500 in gear.
4. Turn on the load bank switches to increase the battery load to equal 40 Amps.
5. Check the ammeter.
6. If the amperage is low,
  - A) Check the load bank for battery draw.
  - B) Reconnect the ammeter between the red wires from one of the regulator/rectifiers and the terminal strip. Retest. You should show about 20 Amps from each regulator/rectifier.
  - C) If the output is still low, check and clean all connections between the battery and the regulator/rectifier plate.
7. If the amperage is correct, but the battery voltage remains low, replace the battery.

## Bench Test

### Diode plate check:

Test the forward diodes between the two yellow wires and the red wire. You should get a reading of about 45K (45,000) on one and a high reading on the other. Check the resistance from each of the yellow wires to case ground, you should get a reading of about 56K (56,000) on one and a high reading on the other. The red wire should read about 14K (14,000) ohms to ground.

### Tachometer Circuit:

Check the resistance between the gray wire and engine ground. You should read above 100K (100,000) ohms. Gray to red, and gray to the yellow wires should be a high reading, usually in the M range